


11 KV

HK 1000




HK1001

HK1002

HK1003

HK1004



Kabel videre til HK1005  
kommer i fase 3